

INSTALLATION MANUAL



MADE IN CANADA

DISCLAIMER

GreenLane Accessories is a division of Western Edison Manufacturing Corp. All of our products are designed for off-road use. Modify your vehicle at your own risk. By choosing to use our products you take full responsibility and liability for any resulting damages to persons or property. Designs are subject to change without notice. Your safety, and the safety of others is very important. CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE. READ AND UNDERSTAND ALL SAFETY PRECAUTIONS AND OPERATING INSTRUCTIONS BEFORE INSTALLING AND OPERATING THIS PRODUCT.

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF WESTERN EDISON MANUFACTURING CORP.
ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF WESTERN EDISON MANUFACTURING CORP IS PROHIBITED.

DESCRIPTION:

**2nd/3rd GEN TACOMA FULL
ENGINE SKID PLATE**

COMPATIBLE WITH:

2005+ TOYOTA TACOMA

DATE UPDATED:

OCTOBER 2020



TOYOTA TACOMA FULL ENGINE SKID PLATE INSTALLATION


APPLICATION: 2005+ TOYOTA TACOMA

PARTS LIST	
SKID PLATE	1
M8-1.25 x 25mm BOLT	2
1/4" FLAT WASHER	2
1/4"-20 x 1/2" CAP SCREW	4

TOOLS REQUIRED
METRIC SOCKET SET

TORQUE SPECS		
THREAD SIZE	HEX BOLT HEAD	TORQUE
6mm	10mm	8 ft/lb
8mm	12 or 13 mm	18 ft/lb
10mm	17mm	23 ft/lb
12mm	19mm	50 ft/lb
14mm	22mm	90 ft/lb
1/4 in	7/16 in	12 ft/lb
5/16 in	1/2 in	19 ft/lb
3/8 in	9/16 in	23 ft/lb
1/2 in	3/4 in	90 ft/lb

1. Remove the factory skid plate by removing the 4 bolts using a 12mm socket (or the 13mm socket if you have aftermarket hardware from a differential drop kit.) You will not reuse this hardware OR the ½” spacers from the drop kit if applicable.
2. Remove factory skid plate brackets using a 17mm socket - 4 of these bolts will be used to install the new GreenLane skid plate, the brackets will not be re-used.



3. Install new skid plate using 4 of the 17mm head factory bolts and tighten.
4. Install supplied M8 bolts at rear mounting points of skid plate.

INSTALL COMPLETE